



Manufacturer

Shenzhen Hanke Technology Co., Ltd

Address

Meipeng SKY311, No.3 Hebei Industrial Zone, Zhongxing Road, Ma'antang Community, Bantian Street, Longgang District, Shenzhen, Guangdong, China, 518000

E-mail


support@bluedee.com



Made in China




Model: SK300



2.0 Mini Sound Bar 16"
Quick Start Guide

What's in the Box?

Check to make sure you have everything below.



1



2



3



4



5



6

1. Soundbar
2. Remote control
3. Optical cable
(Length: 1.8m)
4. AC adapter
5. Quick Start Guide
6. 3.5mm AUX cable
7. Wall mounting kit
8. AUX to RCA audio cable
(Length: 1.5m)




7




8

Get to Know Your 2.0 Mini Sound Bar 16"



Front

1



Back


2

3

4

5

2



6

7

8

9


Controls

1. Status indicator
2. Wall mount
3. Aux in
4. Optical
5. Power

6. Power on / off
7. Source
8. Volume down
9. Volume up

Get to Know Your 2.0 Mini Sound Bar 16"

Remote control



1. Power on off
2. Bluetooth
3. Previous track
4. Music mode
5. TV mode
6. Volume down
7. Mute
8. Optical
9. Aux
10. Next track
11. Play / Pause
12. Movie mode
13. Volume up

Get to Know Your 2.0 Mini Sound Bar 16"

Status indicator

Standby	Solid Red
Optical	Solid Green
Aux in	Solid White
Bluetooth pairing mode	Flashing blue
Bluetooth device connected	Solid blue
Volume up and down	Corresponding to the sound source indicator light flash 1 time
Maximum and minimum volume	Corresponding to the sound source indicator light flash 3 times
Mute	Slow flash
TV mode	Corresponding to the sound source indicator light flash 2 times
Music mode	Corresponding to the sound source indicator light flash 2 times
Movie mode	Corresponding to the sound source indicator light flash 2 times

Let's Get Started!

Here's what you'll need to get set up:



Ruler



Drill



Screwdriver



Level




TV




Computer, Tablet or Smartphone

Remote control Batteries


1



2





3



Power and Aux connection

Steps:

1. Plug the DC cable from the AC adaptor into the Power jack on the back panel, and plug the AC adaptor into the wall socket.
2. Press  to power on/power off.
3. Connect the audio cable to the audio output of any device (such Desktop PC, Laptop, Smartphone Tablet, MP3, TV etc.) with a 3.5 mm headphone output jack or RCA output jack.



Bluetooth Connection

Steps:

1. Turn on the sound bar and select the Bluetooth mode.
2. Activate the Bluetooth function on your device and search for devices nearby.
3. Find " **SK300** " in the search results and tap to connect.
4. The Bluetooth indicator will turn solid blue on upon a successful connection.

But Wait ... There's More!

- The Bluetooth indicator will keep flashing when the sound bar is pairing.
- Please make sure no other active Bluetooth devices are within range, and that the sound bar is within 3ft / 1m away from your device.
- Before starting to play via Bluetooth, please lower the volume to a moderate level.
- For remote control, Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

The Fine Print

USER MANUAL INSERTS FOR FCC ID

1. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be deter


mined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to
- which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

3. RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

(1)  Correct Disposal of this product. This marking indicates that product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

(2) Frequency:2.402 GHz-2.48GHz

(3) The Max. Transmit power: 10 dBm